PARTS / ACCESSORIES

Golight® parts and accessories may be purchased through Golight, Inc. Visit our web store at: http://store.golight.com or contact us at 308.278.3131 or 800.557.0098.

THREE YEAR LIMITED WARRANTY

Golight, Inc. warrants the Golight® against any deemed defects that are due to workmanship for parts or faulty materials, except halogen lamps, for three years from the date of the original purchase. This warranty to the Golight® does not cover damage resulting from unreasonable use or misuse, unreasonable maintenance or loss, or labor costs.

Mounting the light upside down will void the warranty.

Warranty information must be filled out within 30 days of purchase at: http://golight.com/products/registration.html, for warranty protection.

If the Golight® does fail to operate under warranted specifications, Please call 1-308-278-3131 for a Return Goods Authorization number. After receiving an RGA#, send the light and remote controls postage paid, plus $9.95 for shipping and handling to: Golight, Inc. • Service Department • 37146 Old Hwy 17 • Culbertson, NE 69024-8226. No C.O.D.'s accepted. Only the above manufacturer is authorized to perform warranty repair or replace product.

Any consequential damages to person or property are excluded from this warranty. Some states do not allow the exclusion and limitation of incidental or consequential damages, therefore the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights and you may also have other rights.

End of Useful Life

For information regarding the proper disposal/recycling of the light contact Golight at 800.557.0098

Golight Inc
37146 Old Hwy 17
Culbertson, NE 69024
800.557.0098 | 308.278.3131
www.golight.com | info@golight.com

MODEL NUMBERS: 5149, 51494

GOLIGHT®

Instruction Guide

Congratulations

You are now the owner of one of the finest remote control searchlights available today. Thank you for letting Golight® assist you in your lighting application needs. We're proud of our products and the technology that we've developed to ensure our customers the most durable, versatile and powerful searchlights in the lighting industry.

Please read these instructions before using your new Golight®.

GOLIGHT® GOLIGHT® LED



The Golight® is a Portable Searchlight designed to be permanently or temporarily attached to a vehicle for your specific use. The Searchlight with Directional Flexibility is controlled by a wired remote, which gives the operator a full 370° horizontal rotation and a 135° vertical tilt with fingertip control. The Golight® provides superior light penetration with Cr5 PentaBeam™ technology in a halogen configuration or with state of the art P-Vex™ lens and LED technology.

The Golight® Includes:

- Golight® Searchlight
- Wired Remote Control
- Permanent Mounting Shoe
  (Press spring lock to release and remove light.)
- Permanent Mounting Gasket
- Rockguard (not Available with LED units)

An Optional Magnetic Mounting Shoe is available. (www.store.golight.com)

MOUNTING INSTRUCTIONS

Temporary (Suction):

1. Always clean mounting surface with a clean cloth.
2. Remove light from permanent mount shoe by depressing spring-loaded lock and sliding light out.
3. Place suction base on clean, dry surface and move side lever into the locked position.

WARNING: *Check the suction cup frequently to ensure that suction strength is maintained. Temperature variations, rough terrain, grease and dirt affect the length of time that the suction cup will remain in place. Suction mounting is not recommended for road use.*

Permanent:

1. On clean, dry surface, place gasket and shoe in desired location. Using 3/16" screws, attach shoe to vehicle.
2. Slip the Golight® into the shoe. Verify that the spring lock secures the Golight® into the shoe. An optional magnetic mounting shoe is available (see web store).

OPERATION OF GOLIGHT®

1. Place your Golight® into the mounting shoe or attach to the outside of your vehicle (see mounting instructions).
2. Plug your Golight® into your vehicle's cigarette lighter outlet or12 Volt direct battery hookup.
3. Using the remote control, turn on the light by depressing the on/off button.
4. With the 4-way arrows on the remote control, rotate your light to the desired location.
5. The spotlight should not be turned on when the snap on lens cover (rockguard) is attached. (Not applicable for LED)

USAGE:

» This light is intended for off-road and utility use only

» This light is intended to be mounted outside the vehicle while in use

» This light may only be disassembled and repaired by an authorized representative

MISUSE:

» This light is not approved for road or highway use

» This light is not approved for underwater use

» This light is not approved for inverted mounting

» This light is not approved for use inside a vehicle or enclosure and power should be disconnected prior to placing the light in such circumstance

» This light may be damaged if operated in icing conditions

» This light may only be dismantled by an authorized Golight representative

» Any violation of the above referenced misuses will be considered grounds for warranty refusal

IMPORTANT SAFETY INFORMATION

✱ This symbol is to alert you to important operating or servicing instructions that appear in your instructions. Always follow basic safety precautions when using this product to reduce the risk of injury, fire or electric shock.

✱ This light is for off road and utility use only. It is not designed for road use as a driving light.

✱ FCC RULE Part. 15.21 - Changes or modifications made by the user not expressly approved by Golight, Inc. for compliance could void the user's authority to operate the equipment.

For safe and efficient operation of your Golight®, observe these guidelines:

Using your Golight® in icing conditions could damage the gear motors.

The remote must be kept clean and dry to avoid damage to the internal circuitry.